

EasyDrive II

Quick guide to installation



EasyDrive II for MS Windows 95b/98, ME, 2000 and XP; Linux Kernel 2.4 or later; Mac OS X 10.3 or later

You do not need to install a device-specific driver if you are using one of the above operating systems. The EasyDrive II will be automatically recognized by the operating system as a removable media drive (you will see the label «OnSpec»).

Installing the hardware

Please install the EasyDrive II in an unused 3.5" drive bay and connect it to the PC using a 40-way IDE cable. Please do not connect a second device to that IDE cable. Then connect the power supply connector.

Removing the storage media in Windows

You must «unmount» the storage media in Windows before removing it from the drive (right-click on the drive icon and left-click «unmount» in the context menu which is displayed).

Please observe the following points carefully:

- Observe the general guidelines when handling components or modules which can be damaged by electrostatic charge or discharge.
- If you should encounter any problems during the installation or use of this product, please contact our service department and ask for advice. If you do not do this, your guarantee rights may be impaired.

Support hotline, Monday to Friday,
11 am to 3 pm German time (CET):
Phone **+49-511-983 81-70**
or eMail support@altec-cs.com

