# **Transmitters: TT330 Series**



RTD (Pt, Ni, Cu) or 0-450 ohm input 🔶 Universal current/voltage output 🔶 12-32V DC local/bus power

### Description

The TT335 model is a space-saving four-wire transmitter that isolates and converts an RTD sensor input to a proportional control signal. DC current and voltage output are both supported on a single model. An optional DIN rail bus can deliver primary or redundant power to multiple units without wiring.

High-voltage isolation separates the input from the output circuit. Isolation protects from surges, reduces noise, and eliminates ground loop errors. Setup and calibration are fast and easy with a convenient USB connection to your PC and Acromag's Windows configuration software.

Advanced signal processing capabilities, variable range input, and convenient USB programming make this instrument a very versatile temperature measurement device. These transmitters can withstand harsh industrial environments and operate reliably across a wide temperature range with very low drift. They feature RFI, EMI, ESD, EFT, and surge protection plus low radiated emissions.

communication Setup 1/O Confi	g/Test Calbration	
CONFIGURE 1/0		
Input Options	Get I/O Config	
Input Type:	RTD Platinum 100 Ohms, alpha = 0.0	00385 -
Input Filtering:	Medium (150 milliseconds)	•
Output Options		
Break Direction:	Over «ange	
Output Range:	4-20 milliamps	•
Temperature Units		
Celsius	Fahrenheit	Kelvin
1/O Scaling		
-200.00 °C = 4	ImA Out 850.00 °C = 20mA 0	Dut
(Zero-Scale)	(Full-Scale) (-200.00%	C to 850.00°C)
Status No Error		
	Send I/O Config	
TEST 1/O		
Start Poling	Temperature: *C	
Click "Start Poling The LED next to	" to poll the input and display its value. the button will flash when poling is activ	ė.
Click "Stop Poling	to discontinue poling the input.	

TT335 Model software allows you to configure transmitters offline.

TT330 Series Transmitter Configuration Software is downloadable (FREE) from <u>www.acromag.com</u>. Windows® XP. Vista. 7, and 8

The Agility™ Config Tool is downloadable (FREE) at the Google Play Store For Android Devices only

#### **Key Features & Benefits**

- Easy setup and digital calibration via USB with Windows configuration software
- Selectable RTD or linear resistance input type: Pt RTD (100Ω, 200Ω, 500Ω, or 1000Ω), Ni RTD (120 $\Omega$ ), Cu RTD (10 $\Omega$ ), or Resistance  $(0-450\Omega)$
- Universal output connections support ranges up to ±21mA or ±10.5V DC without rewiring
- Pluggable terminals for convenient wiring
- High accuracy, linearity, stability, and reliability
- User-selectable filtering (none, low, med., high)
- Fast response (as low as 32ms)
- Supports normal or reverse-acting output
- Selectable upscale or downscale operation for sensor faults and lead-break detection
- Bus power, local power, or both for redundant power supplies
- 1500V isolation, 3-way (power, input, output)
- Shock (25g) and vibration (4g) resistant
- Wide ambient operation (-40 to 80°C)
- CE compliant. UL/cUL Class I Div 2, ATEX / IECEx Zone 2 approvals



save the file, and download into units later, at your convenience.

## Transmitters: TT330 Series

## TT335 Isolated RTD/resistance input four-wire transmitter

## **Performance Specifications**

IMPORTANT: To prevent damage or errors from grounded PCs and surges, Acromag strongly recommends use of their USB-ISOLATOR when configuring a TT330 Series transmitter.

#### USB Interface

#### **USB** Connector

Type: USB Mini-B type socket, 5-pin. Data rate: 12Mbps. USB v1.1 and 2.0 compatible. Maximum cable length: 5.0 meters.

#### **USB** Transient Protection

Transient voltage suppression on power and data lines.

Driver

Not required. Uses Windows HID drivers.

#### Input

#### **Default Configuration**

 $100\Omega$  Pt RTD,  $\alpha$ =0.00385, -200 to 850°C input, 4-20mA output, upscale break detect, medium filter.

#### Input Configuration

Two-, three- or four-wire sensor input connections.

#### Programs in °C, °K, °F, or ohmic integer values only.

#### Input Ranges

Input Type	Input Range	Accuracy
Pt 100Ω	-200 to 850°C	±0.25°C
Pt 200Ω	-200 to 850°C	±0.30°C
Pt 500Ω	-200 to 850°C	±0.50°C
Pt 1000Ω	-200 to 850°C	±1.00°C
Ni 120Ω (Minco 7-120)	-80 to 320°C	±0.08°C
Cu 10Ω (Minco 16-9)	-200 to +270°C	±1.00°C
Linear Resistance	0 to 250Ω	±0.05Ω
Linear Resistance	0 to 450Ω	±0.10Ω
Linear Resistance	0 to 900Ω	±0.90Ω
Linear Resistance	0 to 2250Ω	±2.25Ω
Linear Resistance	0 to 4500Ω	±4.50Ω

#### Input Scaling Adjust

Zero: 0 to 95% of range, typical. Full scale: 5 to 100% of full scale range, typical.

#### Lead Break (Sensor Burnout) Detection Configurable for either upscale or downscale.

## Output

Range	Over-Range	Resolution
±10V	±10.5V	1 part in 62558
±5V	±5.25V	1 part in 31278
0 to 10V	-0.5527 to +10.5V	1 part in 59293
0 to 5V	-0.27634 to +5.25V	1 part in 60414
±20mA	±21mA	1 part in 62400
0 to 20mA	-1.1054 to 21mA	1 part in 58732
4 to 20mA	–1.1054 to 21mA	1 part in 46984

#### **Output Accuracy**

Better than  $\pm 0.05\%$  of span, typical ( $\pm 0.1\%$  max.) for for nominal input spans. Includes the effects of repeatability, terminal point conformity, and linearization, but does not include sensor error.

#### Output Load

Voltage output: 1K ohms minimum. Current output: 0-525 ohms.

Output Response Time (for step input change)

No filter: 32ms Low filter: 50ms Medium filter: 160ms High filter: 1210ms

Output Ambient Temperature Drift Better than ±80ppm/°C (±0.0080%/°C)

#### Environmental

Operating temperature -40 to 80°C (-40° to 176°F)

#### Storage temperature

-40 to 85°C (-40 to 185°F) Relative humidity

5 to 95% non-condensing Power Requirement

12-32V DC SELV (Safety Extra Low Voltage), 1.3W max.

#### Isolation

1500V AC peak. 250V AC (354V DC) continuous isolation between input, output, and power (3-way).

Shock and Vibration Immunity Vibration: 4g, per IEC 60068-2-6 Shock: 25g, per IEC 60068-2-27

## Electromagnetic Compatibility (EMC) Compliance

Radiated Emissions: BS EN 61000-6-4, CISPR 16 RFI: BS EN 61000-6-2, IEC 61000-4-3 Conducted RFI: BS EN 61000-6-2, IEC 61000-4-6 ESD: BS EN 61000-6-2, IEC 61000-4-2 EFT: BS EN 61000-6-2, IEC 61000-4-4 Surge Immunity: BS EN 61000-6-2, IEC 61000-4-5

#### Approvals

CE compliant. UL/cUL listed Class I Division 2 Groups ABCD. ATEX / IECEx Zone 2.



## General

General-purpose enclosure designed for mounting on 35mm "T-type" DIN rail.

#### Case Material

Self-extinguishing polyamide, UL94 V-0 rated, color light gray. General-purpose NEMA Type 1 enclosure.

#### I/O Connectors

Removable plug-in terminal blocks rated for 12A/250V; AWG #26-12, stranded or solid copper wire.

#### Dimensions

17.5 x 114.5 x 99.0 mm (0.7 x 4.51 x 3.90 inches)

#### Shipping Weight

0.22 kg (0.5 pounds) packed

### **Ordering Information**

#### Models

TT335-0700 Four-wire transmitter, isolated RTD/resistance input

#### Services

#### TT330-Config/Cal

Factory custom configuration/calibration service. Specify input type, input/output zero and full-scale values, filtering, and sensor fault settings on order.

#### Software

TTC-SIP (recommend one kit per customer) Software Interface Package for Acromag TT Series transmitters. Includes configuration software CD-ROM (5040-944), isolator (USB-ISOLATOR) and two USB cables (4001-112, 4001-113).

### Accessories

See www.acromag.com for more information.

#### **USB-ISOLATOR**

USB-to-USB isolator, includes USB cable (4001-112)

#### <u>TT BUS-KIT</u>

DIN rail bus power connector and left/right terminal blocks. One kit supports multiple transmitters.





Tel 877-214-6267 • sales@acromag.com • www.acromag.com • 30765 Wixom Rd, Wixom, MI 48393 USA

## Transmitters: TT Series

## Acromag Agility<sup>™</sup> Config Tool Mobile Application

The Agility<sup>™</sup> Config Tool is a mobile application that allows easy setup and configuration of Acromag TT Series transmitters via a tethered mobile device.

This free app is available for Android devices at the Google Play store at <u>Acromag Agility™ Config Tool</u>.

Demo the software, no need for a module. To enter demo mode simply tap the icon in the upper left corner 8 times.



TT234-0 CONFIGURATION	CONFIG TABLE	CALIBRATION		DIAGNOSTIC CENTER	?	\$	1
INPUT OPTIONS				TT234-0600 WI	RING DI	AGRAMS	
Input Type:	Thermisto	or (Use Table)	►	Potentioment	er Inpu	t Wiring	
				Rheostat/The	rmistor	Input W	iring
Input Filtering:	Medium 🕨		Output/Power Wiring				
OUTPUT OPTIONS				Output Sinkin	g/Sour	cing Wiri	ng
Break Direction:		Under-Range	•				
TEMPERATURE UNITS				-			
Unit:		Celsius	•				
I/O SCALING							
-40.00 °C = 4mA Out							
evice status: Connected							

With a couple of taps, quickly configure input, output, unit and scaling options.



Quick and easy access to the wiring diagram, even offline without internet access.

## **Key Features & Benefits**

- Connects to Acromag TT Series transmitters (except models TT231)
- Requires the use of USB OTG Cable (Acromag part #: 5028-565) and USB A to Mini B Cable (Acromag part #: 4001-113)
- Configures and calibrates TT Series products via phone or tablet running Android 4.3 ICS (Ice Cream Sandwich) or later.
- View wiring diagrams, even without an internet connection
- Perform quick and easy field diagnostics and troubleshooting
- Ideal for field technicians



Tel 877-214-6267 sales@acromag.com www.acromag.com 30765 Wixom Rd, Wixom, MI 48393 USA